

Satellite Meter Settings

Satellite	- W2a C-Band
Frequency	-3951
Polarization	-Horizontal
Symbol Rate	-11200
FEC	-5/6
LNB Voltage	-5.15
LNB Switch	-Off